





### Verbinden der Fernbedienung an die Leuchte

Schalten Sie die Leuchte über den Wandschalter aus, bevor Sie die Leuchte anlernen. Drücken Sie den SETUP Knopf ( ). Halten Sie diesen gedrückt, während Sie die Leuchte über den Wandschalter einschalten. Innerhalb der nächsten Sekunden ertönt ein Piepen (2x) und die Leuchte blinkt. Die Leuchte ist nun an die Fernbedienung angelernt.

### Reset

Schalten Sie die Leuchte zunächst über den Wandschalter aus, um die Leuchte zu reseten. Drücken Sie den ON/OFF Knopf ( ). Halten Sie diesen für ca. 5 sek. gedrückt, während Sie die Leuchte über den Wandschalter einschalten, bis die Leuchte (2x) piept und blinkt.

### Technische Daten:

Betriebsspannung:	3V
Betriebsstrom:	10 mA
Reichweite der Fernbedienung:	10 m
Übertragungsart:	Funk (2,4GHz / 9dBm)
Batterie:	2x 1,5V AAA

### Teach the remote control to the light

Switch off the light via the wall switch before teaching. Press and hold the SETUP button ( ), during you switch on the light via the wall switch. Within the next few seconds, a beep sounds (2x) and the light flashes. The light is taught to the remote control now.

### Reset

To reset the light, first switch of the light via the wall switch. Press and hold the ON/OFF button ( ) for approx. 5 seconds, during you switch on the light via the wall switch, until the light starts beeping (2x) and flashing.

### Specifications:

operation voltage:	3V
operation current:	10 mA
remote distance:	10 m
transmission mode:	radio (2,4GHz / 9dBm)
battery:	2x 1,5V AAA