


INSTRUCTION MANUAL



Cisco SL White 103197
 Cisco SL Black 103198
 Cisco SL Satin 103199



| | | |
|------------------------------------|-----------------------|--|
| <p>1.</p> | <p>2.</p> | <p>5.</p> <p>Warning: When replacing a halogen lamp, wait for it to cool, for a minimum of 5 minutes</p> |
| <p>3.</p> <p>INPUT: AC220~240V</p> | <p>4.</p> | |
| <p>6.</p> | <p>Overall Sizes:</p> | |