


# INSTRUCTION MANUAL



Chico HL 4 Black  
106428

|   |                       |           |
|---|-----------------------|-----------|
| <p>1.</p>                               | <p>2.</p>             | <p>3.</p> |
| <p>4.</p> <p>INPUT: AC220-240V~50Hz</p> | <p>5.</p>             | <p>6.</p> |
| <p>7.</p>                               | <p>Overall Sizes:</p> |           |