INSTRUCTION MANUAL

(NL) Gebruikte symbolen

(GB) Safety Precautions / (FR) Symboles utilisés / (DE) Verwendete Symbole / (PL) Stosowane symbole / (NO) Brukte symboler / (DK) Brugte symboler / (SE) Använda symboler / (FI) Kärbetyt symbolit / (IT) Simboli usati / (ES) Simbolos empleados / (CZ) Použité symbol / (PT) Simbolos utilizados / (GR) Χρησιωροποιούμενα οὐμβολοα



220-240V-50Hz g112mm GU10-AR111 Mnx 50W












Jeany SL Black 3-Phase AR111

107181




TO INSTALL:

- 1) Ensure that the adaptor's **Ground wire** is facing with the **No painting** part in the track rail.
- 2) Push up into track and turn the Switch to lock the adaptor on the track rail.
- 3) Then turn the Phase switch to 1 or 2 or 3 position according of the use you want.

TO REMOVE: Turn off the switch to unlock the adaptor on the track rail.

Removing the adaptor by reversing the above sequence



FittinQ LTD 55 Baker Street, London, W1U 7EU Q A Z Q A

FittinQ B.V. Smaragdweg 52, 5527 LB Hapert, The Netherlands

www.qazqa.nl

SAFETY INSTRUCTION

Please study the instruction manual and below information carefully before installing or using this product. Please keep this user manual for further reference

- The luminaires may only be installed by authorized and qualified technicians according the valid regulations for electrical installation.
- 2. Maintenance of the luminaires is limited to their surfaces. During maintenance no moisture can come into contact with any areas of the terminal connections or voltage control parts.
- The electrical supply must be switched off at the outset, preferably by means of a switch in the distribution box, before any installation, maintenance or repair work is undertaken.
- 4. Exterior lighting must not be installed during rain.
- 5. Take account of the minimal separation distance from other objects and the room required around the fitting.
- If in any doubt, consult a professional, taking local installation requirements into account. Some countries stipulate that lighting may be installed only by registered installers.
- Clamping screws in electrical connections must be adequately tightened. This is particularly the case with 12V low voltage conductors.
- Clean with a clean, dry cloth or brush, use no solvents or abrasives. Avoid dampness on all electrical components
- 9. Take account of all available technical information.
- 10. Meaning of symbols:





Protection Class II: the fitting is doubled insulated and does not require earthing

Protection Class III: the fitting is low voltage

The type of lamp and maximum size and wattage indicated in each lighting unit must not be exceed; different items require different kind of light sources with different bulb icons

The armature is designed to work only with the indicated voltage. Different items require different working voltage.

The luminaire can be used in combination with a dimmer


Minimum distance from lighted objects (meters)

The luminaire can be dimmed by wall switch

The reference light angle and light space of the luminaire

This luminaire cannot be disposed together with normal domestic waste in standard rubbish can, but you have to bring it to a staging area for electrical waste

11. Take note of the symbols when connecting wires:



		(DE)	(GB)	(FR)	(NL)	(PL)	(NO)	(DK)
]	L	Stromführender Leiter	Live conductor	Conducteur	Spanning- voerende draad	Przewód prądowy	Strømførende leder	Strømførende leder
	4	Schutzleiter	Earth conductor	Conducteur de protection (terre)	Aardkabel	Przewód uziemiający	Jordledningen	Jordledningen
	N	Neutralleiter	Neutral	Conducteur	Nulleider	Przewód	Nøytralleder	Neutralleder

	(SE)	(FI)	(IT)	(ES)	(CZ)	(PT)	(GR)
L	Strömförande ledare	Virtajohdin	Conduttore sotto tensione	Conductor de corriente	Vodič pod napětím	Condutor vivo	Ρευματοφόρος αγωγός
	Skyddsledare	Suojajohdin	Conduttore di terra	Conductor de protección	Ochranný vodič	Condutor de terra	Αγωγός γείωσης
N	Neutralledare	Nollajohdin	Conduttore neutro	Conductor neutro	Neutrální vodič	Condutor neutro	Ουδέτερος αγωγός

FittinQ B.V. Smaragdweg 52, 5527 LB Hapert, The Netherlands FittinQ LTD 55 Baker Street, London, W1U 7EU

