



Please note the information contained in these instructions and save this manual.


Technical data:

Adapter output: 12VDC, 600mA, 7.2W, IP44

Remote control : 3V

Instruction for use:

1. There are LEDs on the bottom of the plastic cover.
2. The lighting function is controlled by a remote control.
3. Put the plug through the power supply and work by remote control.
All function for the button is printed on it.



- N1 on/slow : The color changes to different colors slowly
- N2 on/quick : The color changes to different colors quickly
- N3 on/select colors : Press the button to choose one color stable
- OFF + N1&N2 speed
(press this button to increase speed when the N1 or N2 is working)
- N3 brightness
(press this button to increase the brightness when the N3 is working)
- N1&N2 speed
(press this button to decrease speed when the N1 or N2 is working)
- N3 brightness
(press this button to decrease the brightness when the N3 is working)

Warning:

1. Do not put them near the flammable or easy explosive product.
2. Do not open the under pane by oneself.
3. Keep the plastic cover clear and tidy & good light penetrate function.
4. If the item was not work so smoothly, please check the battery inside the remote or change to another direction to have a try.
5. This item is used for both outdoor and indoor.IP44 standard.
6. The external flexible cable of luminaires cannot be replaced; if the cable is damaged, the luminaire shall be destroyed.

