

Please note the information contained in these instructions and save this manual.


Technical data:

Switch power supply output:5VDC,1000mA

Remote control: 3V 1pc CR2025 battery (included)

Instruction for use

- 1. Place the lamp at a selected location on a flat and stable surface.
- 2. Direct towards the wall, insert the connection plug into the lamp and then plug it into the wall socket.
- 3. Switch on the lamp by pushing on button placed on the remote control.





N1 on/slow: The color changes to different colors slowly N2 on/quick: The color changes to different colors quickly

N3 on/select colors: Press the button to choose one color stable

OFF + N1&N2 speed

(press this button to increase speed when the N1 or N2 is working) N3 brightness

(press this button to increase the brightness when the N3 is working)

N1&N2 speed

(press this button to decrease speed when the N1 or N2 is working) N3 brightness

(press this button to decrease the brightness when the N3 is working)

Warning:

- 1. Do not connect the lamp to the power supply while the lamp is still in its packing.
- 2. Avoid any damage on the insulation wire.
- 3. Do not use this lamp outdoors, in contact with water neither in humid places.
- 4. The transformer/charger must be regularly examined. If any part of the transformer/charger is deteriorated it must be immediately repaired or replaced.
- 5. Don't connect the lamp to other sources of energy that the provided one.
- 6. The lamp should be used only with the transformer recommended.
- 7. If the item was not work so smoothly, please check and reset the battery inside the remote control.
- 8. The switch power supply r is not a toy. Always disconnect the lamp from the switch power supply before carrying out its cleaning.

89197 89198

