




WWW.QAZQA.COM



Important:
1. Please use the light after fully assembled.
2. Operating temperature: 65°C max.

Trento HL II

QAZQA