





Depeche HL 3 B-G / W-G 90026 / 91009

CLEANING INSTRUCTION

- 1. Do not clean the lamp with watery washcloth always use dry cotton fabric for cleaning.
- 2. Always shut off the power when cleaning the lamp.

CAUTION

- 1. Keep it away from where the children can touch it in case being scalded.
- 2. Always shut off the power when installing or repairing.

NOTE

Make sure the lamp has been installed according to the specification before inputting the power.

