

INSTRUCTION MANUAL

Drum CL Eco 20/ Drum CL Eco 30 / Drum CL Eco 40



<p>1.</p> <p>OFF</p>	<p>2.</p>	<p>3.</p>
<p>4.</p> <p>Suitable light source: E14, Halogen Max 28W E14, ESL Max 12W</p>	<p>5.</p>	<p>6.</p>

<p>Drum CL Eco 20</p> <p>10 cm</p> <p>20cm</p> <p>1xE14</p>	<p>Drum CL Eco 30</p> <p>10 cm</p> <p>30cm</p> <p>2xE14</p>	<p>Drum CL Eco 40</p> <p>10 cm</p> <p>40cm</p> <p>3xE14</p>
---	---	---