
INSTRUCTION MANUAL



Unchangeable LED Max.48W 3000K RA>80 20000H















- 1. Turn off the power
- 2.Install expansion adhesive in the ceiling
- 3. Fix the bracket with self-tapping screws
- 4. Open the junction box and power-on
- 5. Push the light fixture to ceiling , make "L" hole and bracket on the same line
- 6. Fix ceiling box with toothed screw
- 7.Power-on



SAFETY DIRECTIONS

Please study the instruction manual and below information carefully before installing or using this product. Please keep this user manual for further reference



- 2. Maintenance of the luminaires is limited to their surfaces. During maintenance no moisture can come into contact with any areas of the terminal connections or voltage control parts.
- 3. The electrical supply must be switched off at the outset, preferably by means of a switch in the distribution box, before any installation, maintenance or repair work is undertaken.
- 4. Exterior lighting must not be installed during rain.
- 6. Take account of the minimal separation distance from other objects and the room required around the fitting.
- 7. If in any doubt, consult a professional, taking local installation requirements into account. Some countries stipulate that lighting may be installed only by registered installers.
- 8. Clamping screws in electrical connections must be adequately tightened. This is particularly the case with 12V low voltage conductors.
- 9. When replacing a halogen lamp, wait for it to cool, for a minimum of 5 minutes.
- 10. Clean with a clean, dry cloth or brush, use no solvents or abrasives. Avoid dampness on all electrical components
- 11. Take account of all available technical information.
- 12. Take note of the symbols when connecting wires:
 - N = Neutral
 - L =Live
 - =Earth
- 13. Meaning of symbols:

