


INSTRUCTION MANUAL



Laser HL 4 Black 93116

<p>1.</p> <p>1-1</p> <p>1-2</p>	<p>2.</p> <p>ADJUSTABLE</p>
<p>3.</p>	<p>4.</p>
<p>5.</p> <p>5-1</p> <p>5-2</p>	<p>Overall Sizes:</p> <p>Ø120mm</p> <p>630-920mm</p> <p>1280mm</p> <p>Ø220mm</p>