


"INSTRUCTION MANUAL"




Cortin FL Tripod Black with gold 96522

Assembly Instructions
Instrucciones De Asamblea
Instructions d'Assemblée



For indoor use only. Keep out of the reach of children and animals. Place on flat surface and away from flammable materials. Never operate this appliance if it has a damaged cord, plug or cable. Keep cord away from heated and/or damp areas

CAUTION! Only use Type A 40 Watt bulb or CFL equivalent



- REGULABLE
SHADE
200-240V
50-60HZ
- 220-240V
50-60HZ
- Indoor Use Only
- Home Use Only
- CE
- 2 YEARS

QAZQA

WWW.QAZQA.COM