

# "INSTRUCTION MANUAL"



**Cortin FL Tripod White with Nickel**  
**96523**

Assembly Instructions  
Instrucciones De Asamblea  
Instructions d'Assemblée

## PARTS




**A**



**B**

For indoor use only. Keep out of the reach of children and animals. Place on flat surface and away from flammable materials. Never operate this appliance if it has a damaged cord, plug or cable. Keep cord away from heated and/or damp areas

**CAUTION! Only use Type A 40 Watt bulb or CFL equivalent**



QAZQA

WWW.QAZQA.COM