

# "INSTRUCTION MANUAL"



## Cortin FL Tripod Black with Nickel 96524

Assembly Instructions  
Instrucciones De Asamblea  
Instructions d'Assemblée

### PARTS



A



B

For indoor use only. Keep out of the reach of children and animals. Place on flat surface and away from flammable materials. Never operate this appliance if it has a damaged cord, plug or cable. Keep cord away from heated and/or damp areas


**CAUTION!** Only use Type A 40 Watt bulb or CFL equivalent

1

Place Lamp in room and adjust left to right.  
Tighten screw firmly. See inset below.

Screw in light bulb.  
Plug in electrical  
cord. Turn switch  
ON to test. Close  
Grill and tighten  
securely.

\*Tighten



\*Tighten



QAZQA

WWW.QAZQA.COM