



INSTRUCTION MANUAL



Camelot HL Black Steel 47 96684



STEP: 5
NOT INCLUDED



Overall size:

