
SAFETY DIRECTIONS

Please study the instruction manual and below information carefully before installing or using this product. Please keep this user manual for further reference

- 1. The luminaires may only be installed by authorized and qualified technicians according the valid regulations for electrical installation.
- 2. Maintenance of the luminaires is limited to their surfaces. During maintenance no moisture can come into contact with any areas of the terminal connections or voltage control parts.
- 3. The electrical supply must be switched off at the outset, preferably by means of a switch in the distribution box, before any installation, maintenance or repair work is undertaken.
- 4. Exterior lighting must not be installed during rain.
- 6. Take account of the minimal separation distance from other objects and the room required around the fitting.
- 7. If in any doubt, consult a professional, taking local installation requirements into account. Some countries stipulate that lighting may be installed only by registered installers.
- 8. Clamping screws in electrical connections must be adequately tightened. This is particularly the case with 12V low voltage conductors.
- 9. When replacing a halogen lamp, wait for it to cool, for a minimum of 5 minutes.
- 10. Clean with a clean, dry cloth or brush, use no solvents or abrasives. Avoid dampness on all electrical components
- 11. Take account of all available technical information.
- 12. Take note of the symbols when connecting wires:
 - N =Neutral
 - L =Live
 - =Earth
- 13. Meaning of symbols:



Protection class 3: the fitting is low voltage

Suitable for installing on normal inflammable materials

Observe the indicated minimum distance between the lam and the illuminated materials/objects

Only the self-screening halogen illuminants should be used with the luminaire

Strip the wire to the indicated length 3 x min. 0,75mm²

Connect using the specified cable

The armature can be used in combination with a dimmer. Consult the sales outlet for the correct type

of dimmer(important in the case of 12V fittings)

The maximum wattage indicated in each lighting unit, for example, must not be exceed

This luminaire cannot be disposed together with normal domestic waste in standard rubbish bin, but you have to bring it to a staging area for electrical waste

This luminaire was designed to work only with the indicated voltage








INSTRUCTION MANUAL

Fuze HL Antique Zinc (98120)
Fuze HL Antique Green and Copper (98121)
Fuze HL Antique Brass (98122)









Assembly

- 1. Switch off main power supply.
- 2. & 3. Use screws to mount the bracket on the ceiling.
- 4. Connect the electrical cable provided with the lamp to the mains wire.
- 5. Install the bracket provided with the lamp to connect it with the ceiling.
- 6. Open the middle section of the cage by pulling it down as shown in the image (the cage opens through a hinge mechanism)
- 7. Use 2xE 27 bulbs on the lamp holders.
- 8. Close the hinge after installing the bulbs.
- 9. Restore power, your lamp is now ready to use.

