

INSTRUCTION MANUAL



Pelotas HL Black

<p>1. OFF</p>	<p>2.</p>	
<p>3.</p>	<p>4.</p> <p>INPUT: AC220-240V~50Hz</p>	
<p>5.</p>	<p>6. ON</p>	
<p>Pelotas HL Black 30 98884</p> <p>12*2.5CM 115CM 150CM ∅30CM</p>	<p>Pelotas HL Black 40 98885</p> <p>12*2.5CM 110CM 150CM ∅40CM</p>	<p>Pelotas HL Black 40 98886</p> <p>12*2.5CM 100CM 150CM ∅50CM</p>