



INSTRUCTION MANUAL



Ball 20 Spike
43461
Ball 30 Spike
43462
Ball 40 Spike
43463
Ball 50 Spike
43464



Y : To avoid danger or damage to the external flexible power cable (power supply) for this lamp may only be replaced by the manufacturer, its service representatives or a suitably qualified electrician

