

MAGNIFYING LAMP

NO.:46067

Thank you very much for purchasing our Magnifier Lamp. The Magnifier Lamp is ideal for precise work in home, office and workshop as well as a lot of other important places. Before using the Magnifier Lamp, please read the following instructions.

1. Important data:

A. Magnifier: Ø100mm diameter, 3 diopter

B. Voltage: AC 220V~240V 50HzC. Bulb Type: 60PCS LEDS 5W

2. How to use:

- A. Before use, remove all packing from around the lamp.
- B. Put the lamp on the horizontal table.
- C. Insert the plug into a conveniently located electrical socket.
- D. Switch on using the ON/OFF switch located on the surface of the base.
 - E. To place the head in the desired position.

3. Replacing the Tube:

- A. Always switch off, remove the plug from the mains supply and allow the lamp to cool before changing the LED.
- B. Rotate the head so you can see the underside. Using a suitable screwdriver remove the five small screw that secures the diffuser to the head of the lamp.
- C. Remove the diffuser and place safely to one side.
- D. Remove the LED from the head .Gently put onto the new LED ensuring it is pushed on fully.
- E. Position the new LED into the head, replace the diffuser and tighten the 5 screws to hold it in place.

4. Caution for safe using:

- A. Indoor use only.
- B. Environment temperature:-20°C~40°C.
- C. Humidity:≤95%.
- D. Never disassemble the magnifier lamp unless you are a qualified electrician.
- E. Plug must be taken out while repairing the magnifier lamp.
- F. Never leave the lens unattended in direct sunlight or where light can shine through it. This constitutes a fire hazard.
- If the external flexible cable or cord of this luminare is damaged, it shall be exclusively replaced by the manufacturer or his service agent or a similar qualified person in order to avoid a hazard.

QAZQA