



WWW.QAZQA.COM

MAGNIFYING LAMP

NO.46063

Thank you very much for purchasing our Magnifier Lamp. The Magnifier Lamp is ideal for precise work in home, office, workshop as well as a lot of other important places. Before using the Magnifier Lamp, please read the following instructions.

1. Important data:

Magnifier: $\Phi 5''$, 3 diopter

Voltage: AC220V~240V 50Hz

Tube Type: T5 22W G10q

Ballast: AC220V~240V 22W

2. How to use:

Clamp the bracket to the edge of any horizontal surface which you have chosen. Insert the bottom stem of the arm into the hole in the bracket. Plug in the magnifier lamp.

3. Change of tube:

Switch off the magnifier lamp and take out the plug. Take off the transparent tube protection cover. Replace the broken tube with a new one. Put on the tube protection cover.

4. Important for safe use:

- 1) Indoor use only.
- 2) Environment temperature $-20^{\circ}\text{C}\sim 40^{\circ}\text{C}$.
- 3) Humidity: $\leq 95\%$.
- 4) Never disassemble the magnifier lamp unless you are a qualified electrician.
- 5) Plug must be taken out while repairing the magnifier lamp.
- 6) The magnifier lamp can only be mounted on horizontal surface with thickness from $0.5''\sim 2.5''$.

5. If the external flexible cable or cord of this luminaire is damaged, it shall be exclusively replaced by the manufacturer or his service agent or a similar qualified person in order to avoid a hazard.

QAZQA