

MAGNIFYING LAMP

NO::46064

Thank you very much for purchasing our Magnifier Lamp. The Magnifier Lamp is ideal for precise work in home, office and workshop as well as a lot of other important places. Before using the Magnifier Lamp, please read the following instructions.

- 1. Important data:
 - A. Magnifier: Φ5", 3 diopter
 - B. Voltage: AC 220V~240V 50HzC. Bulb Type: 90PCS LEDS 8W
- 2. How to use:
 - A.Before using, please remove all packaging from around the lamp.
 - B.Securely fasten the supplied table clamp onto a solid flat surface like the edge of table or other similar surface.
 - C,Once the table clamp is secure insert the stem of the lamp into the hole in the clamp.
 - D.Insert the plug into a conveniently located electrical socket the lamp is now ready for use.
 - E.Switch on using the On/Off switch located on top of the head.
 - F.To place the magnifying lens in the desired position simply grip either side of the head and move it as necessary. The adjustable arm has been designed to hold the head in any position you place it in.
- 3. Replacing the Tube:
 - A. Always switch off, remove the plug from the mains supply and allow the lamp to cool before changing the LED.
 - B. Rotate the head so you can see the underside. Using a suitable screwdriver remove the five small screw that secures the diffuser to the head of the lamp.
 - C. Remove the diffuser and place safely to one side.
 - D. Remove the LED from the head .Gently put onto the new LED ensuring it is pushed on fully.
 - E. Position the new LED into the head, replace the diffuser and tighten the screws to hold it in place.
- 4. Caution for safe using:
 - A. Indoor use only.
 - B. Environment temperature:-20°C~40°C.
 - C. Humidity:≤95%.
 - D. Never disassemble the magnifier lamp unless you are a qualified electrician.
 - E. Plug must be taken out while repairing the magnifier lamp.
 - F. Never leave the lens unattended in direct sunlight or where light can shine through it. This constitutes a fire hazard.
- 5. If the external flexible cable or cord of this luminare is damaged, it shall be exclusively replaced by the manufacturer or his service agent or a similar qualified person in order to avoid a hazard.

QAZQA