

SAFETY INSTRUCTION


Please study the instruction manual and below information carefully before installing or using this product.
Please keep this user manual for further reference

- The luminaires may only be installed by authorized and qualified technicians according to the valid regulations for electrical installation.
- Maintenance of the luminaires is limited to their surfaces. During maintenance no moisture can come into contact with any areas of the terminal connections or voltage control parts.
- The electrical supply must be switched off at the outset, preferably by means of a switch in the distribution box, before any installation, maintenance or repair work is undertaken.
- Exterior lighting must not be installed during rain.
- Take account of the minimal separation distance from other objects and the room required around the fitting.
- If in any doubt, consult a professional, taking local installation requirements into account. Some countries stipulate that lighting may be installed only by registered installers.
- Clamping screws in electrical connections must be adequately tightened. This is particularly the case with 12V low voltage conductors.
- Clean with a clean, dry cloth or brush, use no solvents or abrasives. Avoid dampness on all electrical components
- Take account of all available technical information.
- Meaning of symbols:

 This icon indicates the level of water-proof and dust-proof


 Protection Class I: the fitting must be earthed

 Protection Class II: the fitting is doubled insulated and does not require earthing

 Protection Class III: the fitting is low voltage

 Minimum distance from lighted objects (meters)

 The type of lamp and maximum size and wattage indicated in each lighting unit must not be exceeded; different items require different kind of light sources with different bulb icons

 The armature is designed to work only with the indicated voltage. Different items require different working voltage.

 The luminaire can be used in combination with a dimmer







 The luminaire can be dimmed by wall switch

 The reference light angle and light space of the luminaire



This luminaire cannot be disposed together with normal domestic waste in standard rubbish can, but you have to bring it to a staging area for electrical waste

- Take note of the symbols when connecting wires:

	(DE)	(GB)	(FR)	(NL)	(PL)	(NO)	(DK)
	L Stromführender Leiter	(L) Live conductor	(F) Conducteur	(NL) Spanningvoerende draad	(PL) Przewód prądowy	(NO) Strømførende leder	(DK) Strømførende leder
	(E) Schutzleiter	(E) Earth conductor	(F) Conducteur de protection (terre)	(NL) Aardkabel	(PL) Przewód uziemiający	(NO) Jordledningen	(DK) Jordledningen
	N Neutralleiter	(N) Neutral conductor	(F) Conducteur neutre	(NL) Nulleider	(PL) Przewód zerowy	(NO) Nøytralleder	(DK) Neutralleder
	(SE)	(FI)	(IT)	(ES)	(CZ)	(PT)	(GR)
	L Strömförande ledare	(FI) Virtajohdin	(IT) Conduttore sotto tensione	(ES) Conductor de corriente	(CZ) Vodič pod napětím	(PT) Condutor vivo	(GR) Ρευματοφόρος αγωγός
	(E) Skyddsledare	(FI) Suojajohdin	(IT) Conduttore di terra	(ES) Conductor de protección	(CZ) Ochranný vodič	(PT) Condutor de terra	(GR) Αγωγός γείωσης
	N Neutralledare	(FI) Nollajohdin	(IT) Conduttore neutro	(ES) Conductor neutro	(CZ) Neutrální vodič	(PT) Condutor neutro	(GR) Ουδέτερος αγωγός



INSTRUCTION MANUAL

(NL) Gebruikte symbolen

(GB) Safety Precautions / (FR) Symboles utilisés / (DE) Verwendete Symbole / (PL) Stosowane symbole / (NO) Brukte symboler / (DK) Brugte symboler / (SE) Använda symboler / (FI) Käytetyt symbolit / (IT) Simboli usati / (ES) Símbolos empleados / (CZ) Použité symboly / (PT) Símbolos utilizados / (GR) Χρησιμοποιούμενα σύμβολα



Sirocco Fan 50 LED Chrome/White/Wood
105682/105683/105684
Sirocco Fan Black 50/Brass 50
105685/105686



CONTENTS:

1.Safety precaution.....	page2
2.Fan Structure Drawing.....	page3
3.Installation Of Hanger Bracket.....	page4
4.Installation Of Fan Blades.....	page5
5.Installation Of Down Rod/Hanger Ball.....	page6
6.Hanging Of Ceiling Fan.....	page6
7.Wiring Of Ceiling Fan.....	page7
8.Installation Of Canopy.....	page7
9.Installation Of Lightkits.....	page8
10.Ceiling Fan Remote Control Manual.....	page9
11.LED Manual.....	page10
12.Safety Instruction.....	page11

INSTRUCTION MANUAL

Sirocco Fan 50 LED Chrome/White/Wood
105682/105683/105684
Sirocco Fan Black 50/Brass 50
105685/105686



Ceiling Fan
incl.LED QL7001214
1900lm Module
1176/1318/1212lm Lamp
18.5W LED Module
101.5W Total
220-240V~50Hz
3000/4000/6500K
CRI>80
30000 h
15000 ON/OFF

	QR	EAN
<p>(DE) Dieses Produkt enthält eine Lichtquelle der Energieeffizienzklasse F (EN) This product contains a light source of energy efficiency class F (FR) Ce produit comprend une source de lumière de classe d'efficacité énergétique F (NL) Dit product bevat een lichtbron van energie-efficiëntieklasse F (PL) Produkt ten zawiera źródło światła o klasie efektywności energetycznej F (NO) Dette produktet inneholder en lyskilde i energieeffektivitetsklasse F (DK) Dette produkt indeholder en lyskilde af energieeffektivitetsklasse F (SE) Denna produkt innehåller en ljuskälla i energieeffektivitetsklass F (FI) Tämä tuote sisältää energiatehokkuusluokan F valonlähteen (IT) Questo prodotto contiene una sorgente luminosa della classe di efficienza energetica F (ES) Este producto contiene una fuente de luz de la clase de eficiencia energética F (CZ) Tento výrobek obsahuje světelný zdroj třídy energetické účinnosti F (PT) Este produto contém uma fonte de luz da classe de eficiência energética F (GR) Αυτό το προϊόν περιέχει μια φωτεινή πηγή ενεργειακής απόδοσης κλάσης F (SK) Tento výrobok obsahuje zdroj svetla triedy energetickej efektivity F</p>		<p>8718881140167 8718881140174 8718881140181 8718881140198 8718881140204</p>

	<p>(DE) Durch einen Fachmann austauschbare Lichtquelle (nur LED) (EN) Replaceable (LED only) light source by a professional. (FR) Source de lumière remplaçable (LED uniquement) par un professionnel. (NL) Lichtbron (alleen led) te vervangen door een professional. (PL) Wymienne (tylko LED) źródło światła wykonane przez profesjonalistę. (NO) Utskiftbar (kun LED) lyskilde av en profesjonell. (DK) Udskiftelig lyskilde (kun LED), udskiftes af en elektriker. (SE) Ljuskälla (endast LED) utbyttbar genom fackman. (FI) Ammattilainen voi vaihtaa vaihdettavan (vain LED) valonlähteen. (IT) Sorgente luminosa (solo LED) sostituibile da un professionista. (ES) Fuente de luz (solo LED) sustituible por un profesional. (CZ) Vyměnitelný (pouze LED) světelný zdroj odborníkem. (PT) Luz LED (apenas LED) substituível por um profissional. (GR) Η πηγή φωτός (μόνο LED) να αντικαθίσταται από επαγγελματία. (SK) Zdroj svetla (iba LED) vymeniteľný prostredníctvom odborníka.</p>
--	---

	<p>(DE) Durch einen Fachmann austauschbares Betriebsgerät. (EN) Replaceable control gear by a professional. (FR) Contrôleur remplaçable par un professionnel. (NL) Voorschakelapparatuur te vervangen door een professional. (PL) Wymienny układ sterujący przez profesjonalistę. (NO) Utskiftbar kontrollutstyr av en profesjonell. (DK) Udskiftelig igangsætter, udskiftes af en elektriker. (SE) Styrdon utbyttbart genom fackman. (FI) Ammattilainen voi vaihtaa vaihdettavat ohjauslaitteet. (IT) Dispositivo di controllo sostituibile da un professionista. (ES) Dispositivo de control sustituible por un profesional. (CZ) Vyměnitelný předřadník odborníkem. (PT) Dispositivo de controlo substituível por um profissional. (GR) Ο εξοπλισμός ελέγχου να αντικαθίσταται από επαγγελματία. (SK) Predradník vymeniteľný prostredníctvom odborníka.</p>
--	---

CEILING FAN REMOTE CONTROL MANUAL

DIAGRAM OF TRANSMITTER

Type number remote:F2C
 RF frequency range:RF433.92MHz
 Transmit power:6dBm
 Coverage area:15m






DIAGRAM OF RECEIVER



SAFETY PRECAUTION:

IMPORTANT:PLEASE READ BEFORE INSTALLATION

- 1.The installation work must be carried out by a qualified wiring installer.
- 2.Turn off the Electrical Main Switch at the circuit breaker fuse box.
- 3.Using power supply 220-240V/50Hz.
- 4.When mouting the fan,to ensure the safety cable is loop across the ceiling mounting "J" hook.
- 5.The ceiling mounting hook must be able to with hold a min.of 35 pounds.
- 6.The ceiling fan must be mounted at a min.height of 2.3meters of clearance from the floor.
- 7.Do not insert any objects in the path of the blades.
- 8.When all electrical connections are done,store all wires neatly.
- 9.Make sure all screws and connections are tightly screwed and secured.
- 10.The supply wires live and neutral must be connected to a double pole switch having a contact of at least 3min in all poles.

WARNING


TO REDUCE THE RISK OF PERSONAL INJURY,DO NOT BEND THE BLADES BRACKETS DURING ASSEMBLY OR AFTER INSTALLATION.
 DO NOT INSERT ANY OBJECTS IN THE PATH OF THE BLADES.
 TO REDUCE THE RISK OF SHOCK,THIS FAN MUST BE INSTALLED WITH AN ISOLATION WALL CONTROL/SWITCH.

Simplified Declaration of Conformity:

Hereby,FitinQBv declares that the radio equipment type [designation of type of radio equipment] is in compliance with Directive 2014/53/EU.

The full text of the EU declaration of conformity is available at the following internet address: www.qazqa.nl

FAN STRUCTURE DRAWING:



Speed (rpm)			Sound (db)			Application		Function			Motor	
Max rpm	Med rpm	Min rpm	db Max rpm	db Med rpm	db Min rpm	Circulating Air m ³ /min	Max Surface in m ²	Speed Setting	Timer Function yes/no	Seasonal profiles winter/summer/both	Fan Motor AC/DC	Watt Motor
170	140	85	46	40	31	230	Lamp 15m ² FAN 25m ²	3	yes	summer	AC	83W

INSTALLATION OF LIGHTKITS:




fig13




fig14




fig15




fig16


- 1) Install LED lamp.
- 2) Remove one screw from light fixture, unscrew the other screw out 3-4mm
- 3) Connect the lightkit wires to light fixture: Black to Black, Blue to Blue.
- 4) Pointing the holes of lightkis to the screws by pushing up and twist clockwise.
- 5) Fasten the first screw back to the hole and tighten all the screws firmly.
- 6) Carefully lift the acrylic cover by pushing up to light fixture and twist clockwise until it is held tightly in place by the three tabs.
- 7) To check if tighten all the screws and accessories.



Warnings:

Do not poke any objects or fingers through the protective screens
Do not place any objects, such as clothing, on the device
Be careful with long hair. These can be sucked in by the air flow, keep sufficient distance.

WIRING OF CEILING FAN:




Total four colors of wires connected from the top of the motor:

- * Brown: Live wire for fan
- * Black: Live wire for light
- * Blue: Neutral wire
- * Yellow & Green: Earth wire

- 1) Connect the bracket single male end (yellow & green wire) to the motor single female end (yellow & green wire).
- 2) Connect the remote control output 4 male end to the motor 4 female end.
- 3) Connect the remote control input 4 female end to the bracket output 4 male end.

NOTE: ALL THE MALE END AND FEMALE END MUST BE CONNECTED WELL TO ENSURE THE MOTOR AND REMOTE CONTROL WORK NORMALLY.

INSTALLATION OF CANOPY:




- 1) After done up the wiring, attach canopy to the hanger bracket by pushing up and twist to locate screws in the two key holes.
- 2) Tighten the two screws firmly. (fig 12)




Warnings:

Do not poke any objects or fingers through the protective screens
Do not place any objects, such as clothing, on the device
Be careful with long hair. These can be sucked in by the air flow, keep sufficient distance.

INSTALLATION OF HANGER BRACKET:



- 1) To use two Expansion Setscrew to install the hanger bracket firmly.




- 2) To use four long screws to install the hanger firmly.



Warnings:

Do not poke any objects or fingers through the protective screens
Do not place any objects, such as clothing, on the device
Be careful with long hair. These can be sucked in by the air flow, keep sufficient distance.

INSTALLATION OF FAN BLADES:



1) According to indication, insert blades between upper fixed plate and lower fixed plate, using the blade screws and fixing blades onto the upper fixed plate through capacitance gap.

2) Only twist into 3/4 each screw first.



3) Complete install 3 blades on the upper fixed plate.

4) Turn over the motor. Twist the six screws and fix the other side of the 3 blades onto the lower fixed plate.

5) Only twist into 3/4 each screw.

6) Adjust uniformly to the space between 3 blades.





7) Tighten each screw securely onto the motor finally.



Warnings:

Do not poke any objects or fingers through the protective screens
Do not place any objects, such as clothing, on the device
Be careful with long hair. These can be sucked in by the air flow, keep sufficient distance.

INSTALLATION OF DOWNROD/HANGER BALL:



1. Remove the screw and bolt from the hanger ball as fig 6; Remove the "R" pin and cross pin from the downrod.

Notice: The downrod with hanger ball is 6 inch, if it's not enough, please use the 10 inch rod before next step.


2. Put the canopy and the decorative cover into the downrod, then thread the wire through the downrod.

3. Install back the screws and bolt to the hanger ball, ensure to fasten the screws.

4. Insert the downrod into the connector, loosen the two setscrews in the downrod support. Install back the cross pin and secured with the "R" pin. Fasten back the two setscrews.

5. The "R" pin must be properly installed to prevent the cross pin from working loose.

HANGING OF CEILING FAN:



1. Carefully lift the fan and assembly into hanger bracket which is attached to the outlet box.

2. Ensure the rod ball's groove is lined up with tab on the hanger bracket.



Warnings:

Do not poke any objects or fingers through the protective screens
Do not place any objects, such as clothing, on the device
Be careful with long hair. These can be sucked in by the air flow, keep sufficient distance.