SAFETY INSTRUCTION

Please study the instruction manual and below information carefully before installing or using this product. Please keep this user manual for further reference

- 1. The luminaires may only be installed by authorized and qualified technicians according the valid regulations for electrical installation.
- 2 Maintenance of the luminaires is limited to their surfaces. During maintenance no moisture can come into contact with any areas of the terminal connections or voltage control parts.
- 3 The electrical supply must be switched off at the outset, preferably by means of a switch in the distribution box, before any installation, maintenance or repair work is undertaken.
- 4. Exterior lighting must not be installed during rain.
- 5. Take account of the minimal separation distance from other objects and the room required around the fitting.
- 6. If in any doubt, consult a professional, taking local installation requirements into account. Some countries stipulate that lighting may be installed only by registered installers.
- 7. Clamping screws in electrical connections must be adequately tightened. This is particularly the case with 12V low voltage conductors.
- 8. When replacing a halogen lamp, wait for it to cool, for a minimum of 5 minutes.
- 9. Clean with a clean, dry cloth or brush, use no solvents or abrasives. Avoid dampness on all electrical components
- 10. Take account of all available technical information.
- 11. Take note of the symbols when connecting wires:
- N = Neutral L = Live \bigoplus = Earth
- 12. Meaning of symbols:

	For indoor use only, where direct contact with water is impossible
IP20	This icon indicates the level of water-proof and dust-proof
	Protection Class I: the fitting must be earthed
	Protection Class II: the fitting is doubled insulated and does not require earthing
	Protection Class III: the fitting is low voltage
0.5m	Minimum distance from lighted objects (meters)
	Only the self-shielded halogen lamp should be used with the luminaire
8mm	Strip the wire to the indicated length (mm); different items require different length
3x min.0,75mm	Connect using the specified cable; different items require different cables
Max. 50mr GU10 2Max.50W	The type of lamp and maximum size and wattage indicated in each lighting unit must not be exceed; different items require different kind of light sources with different bulb icons
220-240V 50Hz	The armature is designed to work only with the indicated voltage. Different items require different working voltage.
	The luminaire can be used in combination with a dimmer
Light Angl	The reference light angle and light space of the luminaire
	This luminaire cannot be disposed together with normal domestic waste in standard rubbish can, but you have to bring it to a staging area for electrical waste



ραζοα

INSTRUCTION MANUAL











Barrel FL Zinc 96529







Step1 : Carefully unpack all the contents of the lamp and lay them infront of you, so that you have all the parts with you before assembling it together.

Step 2 : You should have all the parts Numbered and pictured as above. (A,B,C,D,E) and additionally an E-27 Bulb

Step 3 : Screw in the bottom three KD Legs (Part C) into the upper KD Legs (part B)

Step 4 : After Screwing the legs as in step 3, screw in the threaded part of B into the lamp body (A)

Step 5 : Use an E-27 Bulb on the lamp holder as shown in the picture above.

Step 6 : Carefully affix the lamp cage (D) on the lamp body (A) with the help of three set screws (E) in the same way as you must have received in your packed lamp box. Descriptive instructions shown on the left.

Q A Z Q A

Step 7 : Connect the plug wire chord set emerging from the lamp into the mains connection, your lamp is now ready to use.

