


INSTRUCTION MANUAL



1800	LM
18	W
2700	K
>80	Ra
30000	H



Plater CL

<p>Ⓐ - step1</p> <p>Fix the expansion screws on the ceiling</p>	<p>Ⓐ - step2</p> <p>Fix the bracket with the screws</p>
<p>Ⓐ - step3</p> <p>Connect the L, N wires</p>	<p>Ⓐ - step4</p> <p>Clip the lamp to the bracket</p>
<p>Ⓐ - step5</p> <p>Tighten the screws in the both sides of lamp</p>	<p>Ⓐ - step6</p> <p>Take out the lamp from the bracket</p>

<p>Plater CL White Round LED Item number: 96806 Overall size: Ø 220x50mm</p>	<p>Plater CL White Round 18W LED PIR Item number: 96807 Overall size: Ø 280x50mm</p> <p>Function: 1.To save the power,it would light on when the environment is less than 100LUX. 2.When there is movement in the sensor area of 6-10m,it lights on automatically. And it lights off after 30-40 seconds without movement.</p>	<p>Plater CL White Round 18W LED LUX Item number: 96808 Overall size: Ø 330x50mm</p> <p>Function: 1.It would light on when the environment is less than 100LUX,and light off when the environment is more than 100LUX.</p>
<p>Plater CL White Square LED Item number: 96809 Overall size: 220x220x50mm</p>	<p>Plater CL White Square 18W LED PIR Item number: 96810 Overall size: 280x280x50mm</p> <p>Function: 1.To save the power,it would light on when the environment is less than 100LUX. 2.When there is movement in the sensor area of 6-10m,it lights on automatically. And it lights off after 30-40 seconds without movement.</p>	<p>Plater CL White Square 18W LED LUX Item number: 96811 Overall size: 330x330x50mm</p> <p>Function: 1.It would light on when the environment is less than 100LUX,and light off when the environment is more than 100LUX.</p>

SAFETY INSTRUCTION

Please study the instruction manual and below information carefully before installing or using this product. Please keep this user manual for further reference

- The luminaires may only be installed by authorized and qualified technicians according the valid regulations for electrical installation.
- Maintenance of the luminaires is limited to their surfaces. During maintenance no moisture can come into contact with any areas of the terminal connections or voltage control parts.
- The electrical supply must be switched off at the outset, preferably by means of a switch in the distribution box, before any installation, maintenance or repair work is undertaken.
- Exterior lighting must not be installed during rain.
- Take account of the minimal separation distance from other objects and the room required around the fitting.
- If in any doubt, consult a professional, taking local installation requirements into account. Some countries stipulate that lighting may be installed only by registered installers.
- Clamping screws in electrical connections must be adequately tightened. This is particularly the case with 12V low voltage conductors.
- When replacing a halogen lamp, wait for it to cool, for a minimum of 5 minutes.
- Clean with a clean, dry cloth or brush, use no solvents or abrasives. Avoid dampness on all electrical components
- Take account of all available technical information.
- Take note of the symbols when connecting wires:
N=Neutral **L=Live** **⊕=Earth**
- Meaning of symbols:

- For indoor use only, where direct contact with water is impossible
- This icon indicates the level of water-proof and dust-proof
- Protection Class I: the fitting must be earthed
- Protection Class II: the fitting is doubled insulated and does not require earthing
- Protection Class III: the fitting is low voltage
- Minimum distance from lighted objects (meters)
- Only the self-shielded halogen lamp should be used with the luminaire
- Strip the wire to the indicated length (mm);different items require different length
- Connect using the specified cable; different items require different cables
- The type of lamp and maximum size and wattage indicated in each lighting unit must not be exceed; different items require different kind of light sources with different bulb icons
- The armature is designed to work only with the indicated voltage. Different items require different working voltage.
- The luminaire can be used in combination with a dimmer
- The reference light angle and light space of the luminaire
- This luminaire cannot be disposed together with normal domestic waste in standard rubbish can, but you have to bring it to a staging area for electrical waste